



# ShareTech UTM Solution

Website  
[www.sharetech.com.tw/en-us](http://www.sharetech.com.tw/en-us)

Sales Info  
[sales@sharetech.com.tw](mailto:sales@sharetech.com.tw)

Tech Support  
[help@sharetech.com.tw](mailto:help@sharetech.com.tw)



## SSL VPN for iOS User Guide (Two-Step Verification)


Install OpenVPN Connect on iOS devices for use with SSL VPN servers.

iOS v18.7.1

### 1. Download the OpenVPN Connect app



### 2. OpenVPN iOS v3.7.2



The IT administrator will provide the download link, or you may consult IT administrator for download instructions.  
URL for example:

[https://\[Wan IP Address or Domain\]:\[HTTPS Port\]/sslvpn.php](https://[Wan IP Address or Domain]:[HTTPS Port]/sslvpn.php)


<https://182.182.182.182:433/sslvpn.php> or <https://domain:433/sslvpn.php>

3. In Chrome or Safari, enter the IP (e.g., <https://182.182.182.182:443/sslvpn.php>) in the address bar.




4. When two-step verification is required by your organization, this screen will be displayed.

Tap "Show Key" and copy the key.




## 5. You can use Microsoft Authenticator, Google Authenticator, or a third-party authenticator.

5-1 Example: Download and install the Microsoft Authenticator app. It shows Verification Code.




5-2 Example: Download and install the Google Authenticator. It shows Verification Code.



## 6. Choose Certificate (.ovpn) profile, and tap “Download”


Example: Download and install the Microsoft Authenticator app. It shows Verification Code.

Certificate(.ovpn) v3.0



### 6-1. How to find downloaded files




a. From address bar.



b. Find “Files”  on your iPhone.



## 7. You can import your profile by doing the following:



## 8. OpenVPN Connect app:

- Enter username.
- Enter Password.


When 2-step verification is enabled, you should enter the **password + verification code** in the password field.

For example: Password is **password**, verification code is **850945**


=> Password field needs to enter **password850945**

The allowable time difference for the verification code is one minute

- Connected.



## 9. You also can check the VPN connection status from Settings.



Once you have imported the profile, select the profile and tap “Connect” to connect to the SSL VPN server (Step 8 or 9).

